

HygiSeat Installation Steps



1



Find the two holes on the toilet bowl.

2



Put the base plate on the toilet bowl.

3



Insert the shims & bolts.

4



Adjust the bolts then fasten the bolts with nuts.

5



Slide the HygiSeat along the slot at the bottom on the top of base placer.

6



Adjust the shims & bolts to make sure the HygiSeat & toilet bowl are aligned, then fasten the nuts.

7



Once bolts are secure & fasten, battery is charged, then the HygiSeat is ready to use.

